



MERCIA MARINA

**HIGH PRESSURE WASH
SAFETY AND OPERATING INSTRUCTIONS**

SAFETY INSTRUCTIONS

1. DIY users are required to read and sign either the Application for DIY use or the Using Dry Dock Sign Off Sheet before operating the High Pressure Wash.
2. Children under the age of 16 are NOT allowed to use the High Pressure wash
3. Operators must wear appropriate PPE (Personal Protective Equipment) before use. (Eye protection/Visor/Hard Hat and suitable clothing/ footwear.
4. The high pressure lance must never be directed towards the body.

OPERATING INSTRUCTIONS

- a) PLEASE CARRY OUT A VISUAL INSPECTION OF THE EQUIPMENT BEFORE USE AND REPORT ANY FAULTS TO THE MARINA OFFICE.
- b) TURN THE ELECTRICAL SUPPLY MASTER SWITCH (SITUATED ON THE DRY DOCK WALL NEXT TO THE HIGH PRESSURE WASHER) IN A CLOCKWISE DIRECTION.
- c) UNCOIL THE HOSE FULLY
- d) FULLY TURN ON THE WATER SUPPLY TO THE MACHINE
- e) TURN THE PRESSURE WASH SWITCH, SITUATED AT THE RIGHT HAND SIDE OF THE HIGH PRESSURE WASHER, TO THE START POSITION (The High Pressure Washer pump will operate).
- f) FIRMLY GRIP THE LANCE AND SQUEEZE THE TRIGGER. If the lance is not operated for 3 minutes the machine will need to be re switched as per instruction (e).
- g) AFTER USE, PLEASE STOW AWAY THE HIGH PRESSURE WASH HOSE ONTO THE REEL AND TURN IT OFF AT THE MASTER SWITCH.
- h) PLEASE REPORT ANY FAULTS TO THE MARINA OFFICE.
- i) THE HIGH PRESSURE WASH IS SERVICED ANNUALLY. PLEASE ENSURE THE SERVICE DOCUMENT IS PRESENT & DISPLAYED NEXT TO THE EQUIPMENT AND DO NOT USE IF THIS IS NOT PRESENT.

Your cooperation in following with the SAFETY AND OPERATING INSTRUCTIONS is appreciated. Failure to adhere to the above instructions can result in injury

